


# Outdoor Mechanical Pin Timer Instructions

## Safety Information

The device must be mounted in a vertical position with the receptacle facing downward and with the receptacle at least 2 FT above the ground level.

## 1. Product Layout

1. Cover
2. Outlet
3. Grounded cord
4. Timer dial



## 2. Installation

This outdoor mechanical timer has 48 pins with 24 hours daily repeat function. Full 15 Amp rating will handle lighting and heavy-duty loads.

Operation instructions:

1. Locate an electrical outlet that is close to the device you want to control.
2. Put the “ON (I)/TIMER (T)” switch located on top of the unit to the “TIMER (T)” position and plug the timer into the outlet.
3. Set the current time - turning clockwise to present time (lines under numbers are in increments of 30 minutes).  
NOTE: Dial is based on AM/PM.
4. Determine desired start time and push down all pins until desired OFF (O) time.  
NOTE: The “pins” are the slices around the dial.
5. Plug your electrical device directly into the timer. Electrical device must be set to “ON (I)” position for the timer control to work properly.
6. Switch on the timer must be set to “TIMER (T)” position for the timer function to work.
7. You may override operation of the timer by setting the “ON (I)” switch to ON (I). Be sure to set switch back to the “TIMER (T)” for proper timer function.
8. In case of power failure, reset the time of day as indicated in steps 3 above.



MADE IN CHINA